


**Regular cleaning guarantees a long and failure-free operation!**

You can avoid potential dead-times of the equipment caused by dirt or end-user complaints!  
(e.g.: coin jams, many rejections, etc.)

**Please pull the counting unit from the machine as far as it will go!**


**OptiCoin \***

Please fold the coin slide open and beginn the cleaning with the enclosed scraper.








**SideCar Basic**

Please fold up the coin tray unit and beginn the cleaning with the enclosed scraper.



**CLEANING WITH SCRAPER WHEN THE BIN IS EMPTY**

You can remove the glued dirt deposits on the **coin run** or the **coin forward triangles** very quickly with the scraper. Please clean the routes as you can see it on the following pictures.




**CLEANING WITH CLEANING CLOTHS - AT LEAST ONCE A WEEK**

With the **wet synthetics cleaning cloths** you can solve the residual dirt and make the surface more slidable for the coins again.

Please fold up the front sensor and clean it. Afterward clean the **coin run** and the **coin forward tray and its triangles**. If necessary you can also clean the coin funnel.

Below you can find some pictures for better demonstration.



Please wipe the solved dirt desiposits from the front sensor, the **coin run** and the **coin forward tray and its triangles** with the dry cleaning cloths.

